



Einhell

PROFESSIONAL



Cordless Eccentric Polisher

CP-EP 18/125 Li BL-Solo

Item No.: 2093330

Ident No.: 21014

Bar Code: 4006825682823

The Einhell CP-EP 18/125 Li BL-Solo cordless eccentric polisher is ideal for professional vehicle care as part of the Power X-Change family. Powered by an Einhell brushless motor, it offers increased power and runtime, with a 10-year warranty on the motor after online registration. Its 8 mm orbital stroke ensures swirl-free results, and the speed is electronically adjustable from 500 to 3,800 rpm. A soft start prevents polish splashes, while ergonomic handles enable precise operation. The Ø 125 mm hook and loop backing pad allows easy accessory changes. Includes 3 polishing pads. Battery and charger sold separately.

Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Brushless motor – more power and longer runtime
- Brushless – 10-year motor warranty upon registration
- Orbital action for optimal, swirl-free polishing finish
- Electronic speed control for material-appropriate work
- Soft start: Gentle start-up without polish splashes
- Quick accessory change with micro hook and loop adhesion
- Continuous operation lock for extended tasks
- Ergonomic handling with knob and additional handle
- Includes 3x polishing pads
- Delivery excludes battery and charger (available separately)



Technical Data

- | | |
|------------------------------------|------------------------------|
| - Voltage | 18 V |
| - Idle speed | 500 - 3800 min ⁻¹ |
| - Diameter polishing/sanding plate | 125 mm |
| - Orbital diameter | 8 mm |



Logistic Data

- | | |
|---------------------------------|--------------------|
| - Product weight (kg) | 2.11 |
| - Gross weight (kg) | 2.84 |
| - Dimensions single packaging | 477 x 150 x 185 mm |
| - Pieces per export carton | 6 Pieces |
| - Gross weight of export carton | 17.5 kg |
| - Dimensions export carton | 495 x 455 x 390 mm |



Available as special accessories



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



Polierpads CP-EP 18/125 Li BL
Autotechnique Accessory
Item No.: 2093247
Bar Code: 4006825684841
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory