



Einhell

CLASSIC



Cordless Outdoor Light

GC-OL 18/1500 Li-Solo

Item No.: 2320120

Ident No.: 21014

Bar Code: 4006825680423

The Einhell GC-OL 18/1500 Li-Solo cordless outdoor lamp provides light in the dark. A powerful lithium-ion battery from the innovative Power X-Change family always ensures optimal brightness for applications indoors and outdoors. Its 36 LEDs generate a cold white light of 7000 K and a brightness of up to 1500 lm, which can be adjusted in 3 steps at the touch of a button. The illumination range is maximum 4 m. The light head (Ø 11 cm) can be rotated horizontally by up to 290° and pivoted vertically by up to 300°. A non-slip retaining clip enables various fastening options. The cordless lamp can be transported via a carrying handle. Delivery does not include battery or charger (sold separately).

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Portable cordless lamp for indoor and outdoor use
- Stepless adjustment of the LED light head
- 36 powerful LEDs for bright illumination
- Brightness adjustment in 3 levels
- Non-slip retaining clip for various mounting options
- Carrying handle for easy transport
- Supplied without battery and charger (sold separately)

Technical Data

- | | |
|---|-----------|
| - Voltage | 18 V |
| - Quantity of LED | 36 Pieces |
| - Luminous flux max. | 1500 lm |
| - Number of brightness adjustment steps | 3 |
| - Luminous color | 7000 K |

Logistic Data

- | | |
|--------------------------------------|----------------------|
| - Product weight (kg) | 0.449 |
| - Gross weight (kg) | 0.593 |
| - Dimensions single packaging | 180 X 93 X 259 mm |
| - Pieces per export carton | 10 Pieces |
| - Dimensions export carton | 485 X 380 X 280 mm |
| - Container quantity (20"/40"/40"HC) | 5520 11330 12590 |



Available as special accessories



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory

Battery-Running-Times

One Battery for All	 shining ¹ (h)	 shining ² (h)
1.5 Ah	7.2	2.4
2.0 Ah	9.6	3.2
2.5 Ah	12	4
3.0 Ah	14.4	4.8
4.0 Ah	19.2	6.4
5.2 Ah	25	8.3
6.0 Ah	28.8	9.6
8.0 Ah	38.4	12.8

Test setup:

- 1) Min. brightness setting
- 2) Max. brightness setting