



Einhell

EXPERT

POWER X-CHANGE

Cordl.Handstick Vacuum Cleaner

TE-SV 18 Li (1x4,0Ah)

Item No.: 2347187

Ident No.: 21014

Bar Code: 4006825684964

The Einhell cordless upright vacuum cleaner TE-SV 18 Li is part of the combinable Power X-Change family. The interchangeable battery system and fast charging technology mean you can work uninterrupted without a cable. With 4 spotlight LEDs and a joint that can be moved around two axes, even dark corners can be thoroughly cleaned. The triple filter system with washable pleated filter and cyclone separator ensure clean exhaust air and efficient suction. The dust collection container can be emptied easily without a bag at the push of a button. With ECO and BOOST mode, the suction power can be adapted to any situation. The vacuum cleaner can be used both as a hand-held vacuum cleaner and for floor cleaning as an upright vacuum cleaner.

Features & Benefits


- Member of the Power X-Change family, 1x 18 V battery required
- 2-in-1 design: Hand and stick Hoover
- Bagless dust container with emptying at the touch of a button
- 3-fold filter system incl. washable pleated filter
- Always-on function for convenient handling
- ECO and BOOST mode for optimum suction power
- Spotlight LEDs on the floor nozzle for good visibility
- Incl. 1x motorised combi floor nozzle
- Incl. 1x 2-in-1 nozzle
- Incl. 1x flexible crevice nozzle
- Incl. wall bracket with space for accessories
- Incl. 1x 4.0 Ah battery and charger

Technical Data

- Dirt bag size 0.6 L

Logistic Data

- Product weight (kg) 1.05
- Gross weight (kg) 3.55
- Dimensions single packaging 245 x 176 x 775 mm
- Pieces per export carton 1 Pieces
- Gross weight of export carton 3.55 kg
- Container quantities (20"/40"/40"HC) 661 | 1352 | 1963



UNLIMITED RUNTIME



ALWAYS-ON FUNCTION





2 IN 1



FLEXIBLE CREVICE NOZZLE



POWER X-CHANGE
1 BATTERY
FOR ALL
CORDLESS TOOLS



Available as special accessories



Replacement brush
Handstick Vacuum Cleaner Acc.
Item No.: 2351265
Bar Code: 4006825661569
Einhell Accessory



washable filter
Handstick Vacuum Cleaner Acc.
Item No.: 2351266
Bar Code: 4006825661576
Einhell Accessory



Accessory set with hose
Handstick Vacuum Cleaner Acc.
Item No.: 2351267
Bar Code: 4006825665017
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory




2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
C1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



Power X-Twincharger 4A
Charger
Item No.: 4512161
Bar Code: 4006825680638
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



5,2 Ah PXC Starter-Kit
 PXC-Starter-Kit
 Item No.: 4512147
 Bar Code: 4006825675153
 Einhell Accessory





18V 4,0Ah PXC Starter Kit C1
 PXC-Starter-Kit
 Item No.: 4512042
 Bar Code: 4006825613704
 Einhell Accessory



4Ah PLUS PXC Starter Kit
 PXC-Starter-Kit
 Item No.: 4512159
 Bar Code: 4006825680331
 Einhell Accessory

Battery-Running-Times

One Battery for All	 running time ¹ (min.)	 running time ² (min.)
	1.5 Ah	19
2.0 Ah	25	11
2.5 Ah	31	13
3.0 Ah	38	18
4.0 Ah	50	22
5.2 Ah	65	28
6.0 Ah	80	35
8.0 Ah	100	44

Test setup:

- 1) ECO
- 2) BOOST