



PROFESSIONAL



GP-LS 18/28 Li BL-Solo

Item No.: 3408320

Ident No.: 21013

Bar Code: 4006825679175

The Einhell Professional cordless pruning shears GP-LS 18/28 Li BL-Solo are ideal for professional gardeners and hobby gardeners. It belongs to the flexibly combinable Power X-Change family. The device is driven by a PurePOWER Brushless motor for enhanced power and longer runtime. Once you register online, the Brushless motor has a 10-year guarantee. The cutting capacity of the pruning shears can be set between 14 and 28 mm at the touch of a button. The durable SK5 steel bypass blades ensure efficient cuts. The handy pruning shears have a locking switch, a sturdy plastic cover

OWER CHANGE

Features & Benefits

and a belt clip. Delivered without battery or charger.

- Member of the Power X-Change family, 1x 18 V battery required
- Brushless motor more power and longer runningtime
- PurePOWER Brushless 10-year motor warranty after registration
- Adjustable cutting capacity for thinner or thicker branches
- Effortless cutting of branches up to 28 mm thickness
- Faster cuts on thin branches with 14 mm cutting capacity
- Bypass blades made from SK5 steel for efficient pruning work
- Clean, sharp cut close to the branch for optimal growth
- Sturdy blade cover for safe storage
- Locking switch for safe transport and storage
- Pressurised ball oiler for easy lubrication of the blade
- Belt clip for optimum carrying comfort
- Comfortable handling thanks to slim design and soft grip
- Supplied without battery and charger (available separately)

Technical Data

- Cutting width 28 mm - Reduced cutting width 14 mm

Logistic Data

- Product weight (kg) 0.812 - Gross weight (kg) 1.3

- Dimensions single packaging 373 x 117 x 75 mm

- Pieces per export carton 8 Pieces 8.5 kg - Gross weight of export carton

- Dimensions export carton 390 x 315 x 250 mm - Container quantity (20"/40"/40"HC) 6144 | 12864 | 16080



















Available as special accessories



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory



18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512108 Bar Code: 4006825652376 Einhell Accessory

Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory



Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory



PXC Battery Mounting Gadget PXC-Battery Accessory Item No.: 4514155 Bar Code: 4006825658774 Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB A1 Battery Item No.: 4511489



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143 Bar Code: 4006825667653 Einhell Accessory



Power X-Boostcharger 8A Charger Item No.: 4512155 Bar Code: 4006825670554 Einhell Accessory

Bar Code: 4006825638578



5,2 Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory



PXC+ 18V 5-8Ah MULTI Battery Item No.: 4511600 Bar Code: 4006825665055 Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery Item No.: 4511629 Bar Code: 4006825673685 Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery Item No.: 4511631 Bar Code: 4006825673692 Einhell Accessory



18V Battery Charger 3,0A - PXC Charger Item No.: 4514095 Bar Code: 4006825655292 Einhell Accessory



PXC+ 18V 4,0Ah SEALED Battery Item No.: 4511627 Bar Code: 4006825673227 Einhell Accessory



PXC+ 18V 4,0Ah Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory



PXC+ 18V 3,0Ah SEALED Battery Item No.: 4511618 Bar Code: 4006825672794 Einhell Accessory



PXC 18V 3,0Ah Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory



3,0 Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory



2,0 Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



4-6 Ah Multi-Ah Power X-Change Plus Battery Item No.: 4511502 Bar Code: 4006825644210

Battery-Running-Times

	- \\\\\
One Battery for All	cutting ¹
	(pieces)
1.5 Ah	1080
2.0 Ah	1450
2.5 Ah	1830
3.0 Ah	2175
4.0 Ah	2900
5.2 Ah	3860
6.0 Ah	4350
8.0 Ah	5800

Test setup:

¹⁾ wood - round dry beech wood Ø 15 mm