



Einhell

PROFESSIONAL



Cordless Pruning Shears

GP-LS 18/28 Li T BL-Solo

Item No.: 3408330

Ident No.: 21013

Bar Code: 4006825679168


The Einhell Professional cordless pruning shears GP-LS 18/28 Li T BL-Solo is an indispensable tool for any garden. It is part of the versatile Power X-Change range, allowing flexible battery sharing across devices. Powered by a PurePOWER brushless motor, it delivers increased power and extended runtimes. Register online to benefit from a 10-year guarantee on the brushless motor. The telescopic handle extends from 1 to 1.6 metres, enabling work up to 3.8 metres high. The cutting head can be adjusted to 7 different angles for precise trimming. The SK5 steel bypass blades ensure clean cuts on branches up to 28 mm thick. The Pruning Lopper includes a locking switch, a blade cover and a belt clip. Delivery without battery or charger.

Features & Benefits

- Member of the Power X-Change family, 1 x 18 V battery required
- Brushless motor – more power and longer running time
- PurePOWER brushless – 10-year motor guarantee after registration
- Effortless cutting of branches up to 28 mm thick
- 2 in 1: Use as convenient pruning scissors or extend to use as telescopic scissors
- Infinitely lockable aluminum telescopic handle (1 - 1.6 m)
- Telescopic scissors for working up to 3.8 m high
- Metal hook for pulling down cut branches
- Trimming head can be swiveled in 7 positions
- Adjustable cutting capacity when used as hand scissors
- SK5 steel bypass blades for efficient cutting
- Clean, sharp cut close to the branch for optimal growth
- Stable blade cover for secure storage
- Interlock switches for safe transport and storage
- Ball pressure oiler for easy lubrication of the blade
- Belt clip for enhanced comfort and ease of use
- Comfortable handling due to slim design and soft grip
- Delivered without battery or charging device (available separately)



BATTERY &
CHARGER
**NOT
INCLUDED**



PUREPOWER
BRUSHLESS



BLADE ANGLE
ADJUSTMENT



7 STEPS

Technical Data

- | | |
|-------------------------|-------|
| - Cutting width | 28 mm |
| - Reduced cutting width | 14 mm |

Logistic Data

- | | |
|--------------------------------------|---------------------|
| - Product weight (kg) | 2.11 |
| - Gross weight (kg) | 3.2 |
| - Dimensions single packaging | 1545 x 197 x 95 mm |
| - Pieces per export carton | 6 Pieces |
| - Gross weight of export carton | 16.5 kg |
| - Dimensions export carton | 1565 x 410 x 300 mm |
| - Container quantity (20"/40"/40"HC) | 714 1554 1776 |



TELESCOPIC




2IN1



BATTERY &
CHARGER
**NOT
INCLUDED**



18 V



max. Ø 2.8 cm



BLADE ANGLE
ADJUSTMENT

Available as special accessories



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
A1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

Battery-Running-Times



cutting¹
(pieces)

One Battery for All	
1.5 Ah	1080
2.0 Ah	1450
2.5 Ah	1830
3.0 Ah	2175
4.0 Ah	2900
5.2 Ah	3860
6.0 Ah	4350
8.0 Ah	5800

Test setup:

1) wood - round dry beech wood Ø 15 mm