



PROFESSIONAL



GP-LS 18/35 Li BL-Solo

Item No.: 3408360

Ident No.: 21014

Bar Code: 4006825684049

The Einhell Professional Cordless Pruning Shears GP-LS 18/35 Li BL-Solo are perfect for trimming roses, shrubs, perennials, and fruit trees - whether for professional or home use. As part of the Power X-Change family, they are compatible with all batteries and chargers in the range. Powered by an Einhell brushless motor, they deliver increased power and a longer lifespan. After online registration, the motor is covered by a 10-year warranty. The sharp SK5 steel bypass blades cut branches up to 35 mm thick without crushing. The cutting capacity can be adjusted to 25 mm at the touch of a button. A metal hook assists in removing cut branches, while a steel frame protects the battery. Supplied without a battery.

WER X-CHANGE

Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Brushless motor more power and longer runtime
- Brushless 10-year motor warranty after registration
- Adjustable cutting capacity for thinner or thicker branches
- Effortless cutting of branches up to 35 mm thick
- Faster cuts on thin branches with 25 mm cutting capacity
- Suitable for working at heights of up to 3 m
- Metal hook for pulling down cut branches
- Bypass blades made of SK5 steel for efficient cutting
- Clean, sharp cuts close to the branch for optimal growth
- Sturdy blade cover for safe storage
- Steel frame for effective battery protection
- Comfortable handling with a slim design and soft grip
- Supplied without battery and charger (available separately)

Technical Data

- Cutting width 35 mm- Reduced cutting width 25 mm

Logistic Data

- Product weight (kg)- Gross weight (kg)2.3

- Dimensions single packaging 1048 x 80 x 128 mm

- Pieces per export carton 4 Pieces- Gross weight of export carton 11.9 kg

Dimensions export carton
Container quantity (20"/40"HC)
1070 x 380 x 280 mm
1024 | 2112 | 2376













Available as special accessories



PXC Battery Mounting Gadget PXC-Battery Accessory Item No.: 4514155 Bar Code: 4006825658774





PXC+ 18V 5-8Ah MULTI Battery Item No.: 4511600

Bar Code: 4006825665055 **Einhell Accessory**



PXC+ 18V 4,0Ah Battery

Item No.: 4511553 Bar Code: 4006825660869

Einhell Accessory



PXC 18V 3,0Ah Battery Item No.: 4511341

Bar Code: 4006825590593 Einhell Accessory



2,0 Ah Power X-Change Battery

Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory



4-6 Ah Multi-Ah Power X-Change

Plus

Battery Item No.: 4511502

Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack

Battery Item No.: 4511629

Bar Code: 4006825673685

Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB

Battery

Item No.: 4511489

Bar Code: 4006825638578



Power X-Fastcharger 4A

Charger Item No.: 4512103

Bar Code: 4006825650228

Einhell Accessory



Power X-Car Charger 3A

Charger

Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory



18V Battery Charger 3,0A - PXC

Charger Item No.: 4514095

Bar Code: 4006825655292 Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766

Einhell Accessory



18V 4,0Ah PXC Starter Kit B1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704

Einhell Accessory



5,2 Ah Power X-Change Plus Battery Item No.: 4511437

Bar Code: 4006825616606 Einhell Accessory

PXC+ 18V 4,0Ah SEALED Battery Item No.: 4511627

Bar Code: 4006825673227

Einhell Accessory



PXC+ 18V 3,0Ah SEALED Battery Item No.: 4511618

Bar Code: 4006825672794

Einhell Accessory



3,0 Ah Power X-Change Plus

Battery Item No.: 4511501

Bar Code: 4006825644197 Einhell Accessory



4,0 Ah Power X-Change


Battery

Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack

Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory



Bar Code: 4006825673692

Einhell Accessory



2x2 Power X-Quattrocharger 4A

Charger Item No.: 4512102

Bar Code: 4006825649536

Einhell Accessory



Power X-Twincharger 3A

Charger Item No.: 4512069

Bar Code: 4006825629729

Einhell Accessory



Power X-Boostcharger 8A

Charger Item No.: 4512155 Bar Code: 4006825670554 Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory

Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143 Bar Code: 4006825667653

Battery-Running-Times

	4111
One Battery for All	cutting ¹
	(pieces)
1.5 Ah	1300
2.0 Ah	1700
2.5 Ah	2300
3.0 Ah	2800
4.0 Ah	3500
5.2 Ah	4800
6.0 Ah	5600
8.0 Ah	7100

Test setup:

¹⁾ wood - round dry beech wood Ø 15 mm