



Einhell

EXPERT PLUS



Cordless Hedge Trimmer

GE-CH 18/50 Li-Solo

Item No.: 3410910

Ident No.: 11018

Bar Code: 4006825635645

The GE-CH 18/50 Li cordless hedge trimmer is a very efficient tool which provides good service for the trimming of hedges, shrubs and bushes on large grounds and allotments where there is no connection to the electric power grid. For a long service life the gearing is made of metal, for clean cutting results the blades are made of laser-cut and diamond-ground steel.

Features & Benefits

- Blades made of laser-cut and diamond-ground steel
- Adjustable additional handle
- Swivel handle
- Handy
- Metal gearing for a long life
- Two-hand safety switch
- Aluminium cover over cutters
- Shock guard with holder for wall mount
- Sturdy cutter guard for storage and transportation
- Supplied without battery and charger (available separately)



Technical Data


- | | |
|-------------------------|------------------------|
| - Blade length | 570 mm |
| - Cutting length | 500 mm |
| - Spacing between teeth | 16 mm |
| - Cuts per minute | 2200 min ⁻¹ |

Logistic Data


- | | |
|--------------------------------------|--------------------|
| - Product weight | 2.46 |
| - Gross weight single packaging | 2.83 kg |
| - Dimensions single packaging | 970 x 120 x 170 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 12.5 kg |
| - Dimensions Export Carton | 975 x 260 x 250 mm |
| - Container quantity (20"/40"/40"HC) | 1568 3328 3744 |
| - Product weight | 2.46 kg |



ADJUSTABLE HANDLE



DIAMOND GRINDED KNIFE / LASERCUT KNIFE



WALL HOLDER



ALUMINIUM BLADE COVER



Available as special accessories



18V 1.5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512021
Bar Code: 4006825601350
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512041
Bar Code: 4006825613698
Einhell Accessory



18V 4,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,6Ah P-X-C Plus
Battery
Item No.: 4511436
Bar Code: 4006825616590
Einhell Accessory



18V 30min Power-X-Change
Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory



18V 5,2 Ah P-X-C Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power-X-Boostcharger 6 A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



Power-X-Twincharger 3 A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory