



Einhell

PROFESSIONAL



CI Pole-Mounted Powered Pruner

GP-LC 18/20 Li T BL-Solo

Item No.: 3410971

Ident No.: 21014

Bar Code: 4006825681871

The Einhell Professional cordless pole pruner GP-LC 18/20 Li T BL-Solo is a reliable tool of the Power X-Change family for cordlessly cutting trees. The tool is driven by an Einhell Brushless motor for extra power and a longer running time. Once you register online, there is a 10-year warranty on the motor. The telescopic pole can be adjusted up to 2.5 m in length without tools. The pole pruner with its 18 cm cutting length and OREGON guide bar and chain is equipped with automatic chain lubrication. The integrated metal hook makes it easier to grab and pull down branches. A guide bar cover is supplied for safe transportation. Battery and charger not included.

Features & Benefits

- A member of the Power XChange family, 1 x 18 V battery required
- Brushless motor – more power and longer running time
- Brushless – 10-year warranty on motor after registration
- Telescopic handle which can be infinitely adjusted without tools
- OREGON quality guide bar and chain
- Automatic chain lubrication via oil container with sight glass
- Metal gearbox for a long service life
- Metal hook for gripping and pulling down branches
- Comfortable grip thanks to integrated soft-grip surfaces
- Additional rubberised support surface for secure operation
- Steel frame protects the batteries against shocks
- Guide bar cover for safe storage
- Incl. hexagon key on the device for retightening the chain
- Incl. carrying strap for ergonomic working
- Battery and charger not included (available separately)

Technical Data

- Sword length	200 mm
- Cutting length	18 cm
- Cutting speed	7 m/s
- Capacity of oil tank	85 mL
- Length of telescope bar	250 m

Logistic Data




- Product weight	3.73 kg
- Gross weight single packaging	5.5 kg
- Dimensions single packaging	1120 x 193 x 95 mm
- Pieces per export carton	3 Pieces
- Gross weight export carton	17 kg
- Dimensions export carton	1135 x 305 x 215 mm
- Container quantity (20"/40"/40"HC)	1080 2280 2736



AUTOMATIC CHAIN LUBRICATION



ROBUST METAL HOOK



Available as special accessories



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



Ersatzkette 20cm 1,1 33T 3/8
Chain Saw Accessory
Item No.: 4500193
Bar Code: 4006825664577
Einhell Accessory



Ersatzschwert 200 mm
Chain Saw Accessory
Item No.: 4500117
Bar Code: 4006825569100
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Battery-Running-Times



cutting¹
(pieces)

One Battery for All

1.5 Ah	27
2.0 Ah	39
2.5 Ah	54
3.0 Ah	73
4.0 Ah	99
5.2 Ah	127
6.0 Ah	148
8.0 Ah	198

For best performance select a battery with at least 3.0 Ah

Test setup:

1) wood - scantling 70x70 mm