



Einhell

POWER X-CHANGE

Cordless Lawn Trimmer
GC-CTD 18/251 (1x2,0Ah)

Item No.: 3411292

Ident No.: 21016

Bar Code: 4006825693782

The Einhell cordless trimmer GC-CTD 18/251 ensures precise lawn care in hard-to-reach areas and along lawn edges. As part of the Power X-Change battery platform, the device is powered by a 18-V battery. The cordless trimmer is supplied with a 2.0 Ah PXC battery and a charger. With a cutting width of 25 cm, an idle speed of 8,400 rpm and 1.6 mm-thick line, the tool operates powerfully and reliably. The continuously adjustable telescopic guide bar, the adjustable additional handle and the soft-grip surfaces ensure comfortable handling. The Flowerguard protects plants and trees from damage. Thread spool with automatic jogging mechanism included.

Features & Benefits

- A member of the Power X-Change platform; 1 x 18 V battery required
- Infinitely telescopic guide bar
- Flowerguard protects plants and trees from damage
- Soft grip surfaces for comfortable handling
- Incl. 1x thread spool with automatic jogging
- Scope of delivery includes 2.0 Ah PXC battery and charger

Technical Data

- Cutting width (trimmer line)	25 cm
- Idle speed max.	8400 min ⁻¹
- Motor voltage	18 V
- Thread spool type	Single-thread spool
- Thread tracking type	Tipp automatic
- Trimmer line diameter	1.6 mm
- Trimmer line length	500 cm

Logistic Data

- Product weight	2.115 kg
- Gross weight	3.495 kg
- Dimensions single packaging	940 mm x 185 mm x 120 mm
- Pieces per export carton	4 pcs
- Gross weight of export carton	14.5 kg
- Dimensions export carton	960 mm x 400 mm x 265 mm
- Container quantities (20"/40"/40"HC)	1024 pcs 2080 pcs 2340 pcs



Available as special accessories



Cordless Trimmer Spool, 25 cm
Cutting Width
Lawn Trimmer Accessory
Item No.: 3405113
Bar Code: 4006825680393



PXC Battery Wall Bracket
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



PXC 18V 4,0Ah C01
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 4,0Ah TABLESS SEALED
Battery
Item No.: 4511678
Bar Code: 4006825685107
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



Power X-Twincharger 4A
Charger
Item No.: 4512161
Bar Code: 4006825680638
Einhell Accessory



Power X-Charger 0,8A
Charger
Item No.: 4512165
Bar Code: 4006825685084
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory





18V 2.5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory



2x 5.2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



5.2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory

Battery-Running-Times

Battery Capacity	2.0 Ah	2.5 Ah	3.0 Ah	4.0 Ah	5.2 Ah	6.0 Ah	8.0 Ah
Performance	47 min	58 min	70 min	93 min	121 min	140 min	186 min

Max. running time per battery charge