



Einhell

CLASSIC



Cordless Lawn Mower

GC-CM 36/51 S Li BL
(2x5,2Ah)

Item No.: 3413390

Ident No.: 21015

Bar Code: 4006825686661

The Einhell Cordless Lawn Mower GC-CM 36/51 S Li BL (2x5.2Ah) is part of the Power X-Change family. Twin-Pack technology delivers double the power. It is powered by an Einhell brushless motor for increased performance and longer runtime. A 10-year motor warranty applies with online registration. With a 51 cm cutting width, it's suitable for lawns up to 750 m². Rear-wheel drive makes mowing easier. The cutting height can be set in 9 stages from 25 to 80 mm. A height-adjustable, foldable handle and a 50 L grass collection bag with fill level indicator provide added comfort. A robust steel deck ensures durability, while ECO mode extends battery life. Supplied with 2x 5.2 Ah batteries and a twin charger.

Features & Benefits

- Member of Power X-Change family, needs 2x 18V batteries
- Brushless motor for more power and longer runtime
- Brushless – 10-year motor warranty with registration
- Twin-Pack: 2x 18V PXC batteries for extra power
- ECO mode extends runtime
- 9-step central cutting height adjustment
- Foldable, height-adjustable handlebar
- Wheel drive with variable speed control
- Grass box with fill level indicator
- Durable steel deck for long life
- Ideal for lawns up to 750 m²
- Includes 2x 5.2Ah PXC batteries & 1x twin charger




Technical Data

- Accumulator 18 V (2x) | 5.2 mAh | Li-Ion
- Idle speed 3000 min⁻¹
- Cutting width 51 cm
- Cutting height adjustment 9 | 25-80 mm | central
- Capacity of catching device 50 L
- Wheel diameter front 178 mm
- Wheel diameter rear 204 mm



Logistic Data

- Gross weight (kg) 30.8
- Product weight (kg) 25.63
- Dimensions single packaging 848 x 578 x 440 mm
- Pieces per export carton 1 Pieces
- Gross weight export carton 30.8 kg
- Dimensions export carton 850 x 575 x 430 mm
- Container quantity (20"/40"/40"HC) 130 | 270 | 324



Available as special accessories



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



Ersatzmesser GP-CM 36/52 S BL
Lawn Mower Accessory
Item No.: 3405980
Bar Code: 4006825672473
Einhell Accessory



Power X-Charger 0,8A
Charger
Item No.: 4512165
Bar Code: 4006825685084
Einhell Accessory

PXC-Alliance Contact block
PXC-Battery Accessory
Item No.: 4512166
Bar Code: 4006825686098
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
C1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



Power X-Twincharger 4A
Charger
Item No.: 4512161
Bar Code: 4006825680638
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory




4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512170
Bar Code: 4006825686029
Einhell Accessory

Battery-Running-Times

One Battery for All	 lawn mowing ¹ (m ²)
1.5 Ah	215
2.0 Ah	290
2.5 Ah	360
3.0 Ah	430
4.0 Ah	575
5.2 Ah	750
6.0 Ah	865
8.0 Ah	1100

For best performance select a battery with at least 2.5 Ah

Test setup:

1) lawn