



Einhell

CLASSIC



Cordless Scarifier / Aerator

GC-SC 18/28 DS Li-Solo

Item No.: 3420625

Ident No.: 21014

Bar Code: 4006825682496

The Einhell Cordless Scarifier-Aerator GC-SC 18/28 DS Li-Solo offers flexible, cordless lawn care with the Power X-Change system. Double-slot technology with two battery slots ensures longer run times. Powered by an Einhell Brushless Motor for enhanced power and durability, with a 10-year motor warranty upon online registration. Compact storage and easy transport thanks to the foldable handle. Includes a 28 cm blade roller; compatible with a separately available aerator roller to convert into a 2-in-1 tool. Delivered without battery and charger.

Features & Benefits


- Member of the Power X-Change family, 1x 18 V battery required
- Brushless motor – more power and longer runtime
- Double slot function: 2 battery slots, double runtime
- 2-in-1: Scarifier and aerator
- 3-step working depth adjustment
- Foldable guide handle for space-saving storage
- Carrying handle for easy transport
- Incl. 1x blade roller
- Compatible with 28 cm wide aerator roller (available separately)
- Delivery without battery and charger (available separately)

Technical Data

- Working width	280 mm
- Number of knives	12 Pieces
- Wheel diameter front	150 mm
- Wheel diameter rear	100 mm

Logistic Data

- Tool weight	6.76 kg
- Gross Weight	8.92 kg
- Dimensions single packaging	504 x 486 x 248 mm
- Pieces per export carton	1 Pieces
- Gross weight of export carton	8.92 kg
- Dimensions export carton	515 x 488 x 242 mm
- Container quantity (20"/40"/40"HC)	396 864 960



Available as special accessories



Aerator roller GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405941
Bar Code: 4006825658804
Einhell Accessory



Catch Bag GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405940
Bar Code: 4006825658798
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



Scarifierroller GC-SC 18/28 Li
Scarifier Accessory
Item No.: 3405942
Bar Code: 4006825658811
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

Battery-Running-Times



scarifying¹
(m²)

One Battery for All

1.5 Ah	120
2.0 Ah	160
2.5 Ah	200
3.0 Ah	240
4.0 Ah	320
5.2 Ah	420
6.0 Ah	480
8.0 Ah	700

Test setup:

1) dethatch