



Einhell

EXPERT



Cordless Grout Cleaner

GE-CC 18/110 Li E-Solo

Item No.: 3424070

Ident No.: 21014

Bar Code: 4006825681918

The Einhell cordless joint cleaner GE-CC 18/110 Li E-Solo removes moss, weeds, and grass from joints with a powerful 18V Power X-Change battery. A 2-point safety switch and speed control ensure safe, material-friendly operation. The tool-free adjustable guide wheel keeps the device parallel to the joint for precise results. A transparent splash guard with adjustable angle and guideline protects against dust. The telescopic handle with auxiliary grip, including a brush compartment, ensures ergonomic comfort. Includes nylon and steel brushes, both tool-free replaceable. Battery and charger sold separately.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- 2-point safety switch for optimum safety
- Speed electronics for individual speed adjustment
- Height-adjustable guide wheel for ideal distance to the floor
- Transparent protective cover with guide line
- Telescopic guide rail for back-friendly working
- Adjustable additional handle incl. brush storage compartment
- Quick and tool-free brush change
- Incl. 1x Ø 110 mm nylon brush for sensitive surfaces
- Incl. 1x Ø 110 mm steel brush for powerful weed removal
- Supplied without battery and charger (sold separately)

Technical Data

- | | |
|---------------------|-------------------------------|
| - Diameter of brush | 110 mm |
| - No-load speed | 1150 - 1500 min ⁻¹ |

Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 2.3 |
| - Gross weight (kg) | 3.4 |
| - Dimensions single packaging | 954 x 223 x 125 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight of export carton | 16.2 kg |
| - Dimensions export carton | 970 x 455 x 265 mm |
| - Container quantity (20"/40"/40"HC) | 928 1920 2160 |



TOOL-FREE BRUSH CHANGE





HANDLE INCL. STORAGE BOX



HEIGHT ADJUSTABLE WHEEL



INCL. NYLON AND STEEL BRUSH



Available as special accessories



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Battery-Running-Times

One Battery for All		
	cleaning ¹ (min.)	cleaning ² (min.)
1.5 Ah	55	40
2.0 Ah	70	55
2.5 Ah	85	70
3.0 Ah	110	80
4.0 Ah	140	110
5.2 Ah	165	140
6.0 Ah	220	165
8.0 Ah	280	220

Test setup:

- 1) nylon + steel
- 2) nylon + steel