



Einhell



Cordless Spot Cleaner

TE-SCL 18/200 Li-Solo

Item No.: 3437130

Ident No.: 21015

Bar Code: 4006825687026

The Einhell cordless spot cleaner TE-SCL 18/200 Li-Solo is a handy 3-in-1 cleaner for carpets, upholstery and textiles. As part of the Power X-Change battery platform, it can be used in combination with any PXC battery. With the 3-in-1 function, stains can be moistened, brushed out and absorbed directly. The functions can be controlled individually. The rotating brush roller with a working width of 59 mm removes wet stains, the fixed brush attachment is suitable for dried dirt. Both rollers can be exchanged without tools. Clear and dirty water tanks (200 ml each) are removable and dishwasher-safe. Delivery incl. cleaning tool for cleaning the brushes. Battery and charger not included.

Features & Benefits

- A member of the Power XChange family; 1 x 18 V battery required
- 3-in-1: Moisten stains, brush to loosen dirt, extract
- Trigger for controlling the water/detergent supply
- ON button for controlling the suction function
- Brush button for controlling the rotating brush
- Removable clear water tank (also suitable for cleaning agents)
- Removable dirty water tank
- Tanks and nozzle dishwasher-safe up to 60 °C
- Easy-to-change brush
- Rotating brush roller for wet stains
- Fixed brush attachment for dried stains
- Incl. cleaning tool for cleaning the brushes
- Ergonomic handle with soft grip
- IPX4-compliant water-proof battery cover
- Battery and charger not included (available separately)



Technical Data

- Voltage 18 V
- Fresh water tank volume 0.2 L
- Dirt water tank volume 0.2 L

Logistic Data

- Gross weight (kg) 3.25
- Product weight (kg) 2.1
- Pieces per export carton 4 pcs
- Gross weight of export carton 14 kg
- Container quantity (20"/40"/40"HC) 1024 | 2140 | 2460
- Dimensions export carton 585 x 575 x 335 mm
- Dimensions single packaging 560 x 280 x 155 mm

ON DEMAND WATER SUPPLY

REMOVABLE TANKS

CHANGEABLE BRUSH

TOP RACK DISHWASHER-SAFE TRANSPARENT PARTS (UP TO 60°C)

18 V

70 mbar SUCTION POWER

450 l/min AIR VOLUME

3in1
· MOISTEN
· BRUSHING
· VACUUM

Available as special accessories



Brush TE-SCL 18/200 Li
Spot Cleaner Accessory
Item No.: 3437131
Bar Code: 4006825690309
Einhell Accessory



Rotat. Brush TE-SCL 18/240 Li
Spot Cleaner Accessory
Item No.: 3437132
Bar Code: 4006825690323
Einhell Accessory



PXC Battery Protector
PXC-Battery Accessory
Item No.: 4140151
Bar Code: 4006825670844
Einhell Accessory



Power X-Charger 0,8A
Charger
Item No.: 4512165
Bar Code: 4006825685084
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



PXC 18V 4,0Ah
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
C1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825655695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



Power X-Twincharger 4A
Charger
Item No.: 4512161
Bar Code: 4006825680638
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory





18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



18V 2,5Ah PXC Starter Kit - ZG
PXC-Starter-Kit
Item No.: 4512170
Bar Code: 4006825686029
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory

Battery-Running-Times

Battery Capacity

Performance