



#### **PXC-Battery Accessory**

### **PXC Battery Protector**

Item No.: 4140151 Ident No.: 21012 Bar Code: 4006825670844

The Original Einhell protective battery cover is designed for all 18V Power X-Change batteries and protects them from any kind of dust, dirt, moisture and splash water. This ensures the longevity of the Power X-Change batteries. The protective battery cover can be used with all devices with a groove above the battery holder. The sheath is fastened in this groove. The battery cover is made of high-quality, resistant silicone and is especially suitable as an accessory for the Einhell cordless window cleaner BRILLIANTO, the cordless pressure cleaning gun HYPRESSO 18/24, the cordless pipe cleaner TE-DA 18/760 Li and the cordless pressure sprayer GE-WS 18/10 Li. The battery protection is supplied without a battery.

## **Features & Benefits**

- Suitable for all Einhell 18 V Power X-Change batteries
- Protection against dust, moisture and splash water
- Versatile use thanks to optimal fit
- Easy attachment to the device via groove above the battery holder
- Cover made of high-quality, resistant silicone
- Suitable for Einhell battery-powered window cleaner BRILLIANTO
- Compatible with battery pressure washer gun HYPRESSO 18/24 Li
- Accessories for cordless pipe cleaner TE-DA 18/760 Li
- Can be combined with battery-powered pressure sprayer GE-WS 18/10
- Supplied without battery (sold separately)

# **Technical Data**

## Logistic Data

- Product weight (kg)
- Gross weight (kg)
- Dimensions single packaging
- Pieces per export carton
- Gross weight of export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)

0 0.11 100 x 90 x 132 mm 48 Pieces 6.8 kg 430 x 420 x 430 mm 17280 | 34608 | 42000







