



Einhell

EXPERT



Automatic Cordless Garden Pump

**AQUINNA 18/30 F LED
AUTOMATIC**


Item No.: 4180460

Ident No.: 21014

Bar Code: 4006825681512

Features & Benefits

- Member of the Power X-Change family, 1x18V battery needed
- Double Runtime Technology: 2 battery slots, double the runtime
- Automatic switch-on and switch-off when water is required/stopped
- Automatic: Efficient battery utilisation for longer use
- Power level switch: ECO and BOOST mode
- LED battery charge level indicator directly on the device
- LED display for reading status and possible errors
- Pre-filter to protect against dirt in the intake water
- Bleeder screw for efficient suction
- Large water filler opening with water fill indicator
- Frost protection thanks to water drain plug
- Suction indicator for easy reading of suction height and pressure
- Dirt indicator: Quickly recognise dirty filters
- Practical carrying handle for easy transport
- Pump base with hole for secure, permanent attachment
- High-quality metal suction and pressure connections
- Dry-running protection for long-lasting use of the pump
- Incl. non-return valve and robust mechanical seals
- Supplied without battery and charger (available separately)



Technical Data

- Voltage	18 V
- Max. delivery capacity	3000 L/h
- Max. delivery height	28 m
- Max. suction height	6 m
- Suction connection	33,3mm (R1 AG)
- Pressure connection	33,3mm (G1 IG)



Logistic Data

- Product weight (kg)	4.4
- Gross weight (kg)	5.4
- Dimensions single packaging	520 x 230 x 335 mm
- Pieces per export carton	3 Pieces
- Gross weight of export carton	14.7 kg
- Dimensions export carton	715 x 540 x 350 mm
- Container quantity (20"/40"/40"HC)	576 1188



Available as special accessories



Suction hose 4 m, Plastic
Pump Accessory
Item No.: 4173635
Bar Code: 4006825549058
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
A1
Battery
Item No.: 4511489
Bar Code: 4006825638578



accessorysetpressuride (OFP)
Pump Accessory
Item No.: 4173762
Bar Code: 4006825663266
Einhell Accessory



Power X-Caravan Charger 3A
Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



Saug Schlauch 4 m Messing
Pump Accessory
Item No.: 4173630
Bar Code: 4006825549133
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory



Suction hose 7 m, Plastic
Pump Accessory
Item No.: 4173645
Bar Code: 4006825549102
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



Adapter 33,3 mm (1") AG
Pump Accessory
Item No.: 4173761
Bar Code: 4006825662733
Einhell Accessory



accessorysetsuction&press(OFP)
Pump Accessory
Item No.: 4173763
Bar Code: 4006825663273
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



Saug Schlauch 7 m Messing
Pump Accessory
Item No.: 4173640
Bar Code: 4006825549171
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



PXC 18V 4,0Ah
Battery
Item No.: 4514079
Bar Code: 4006825674316
Einhell Accessory (Discounter)



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210

Battery-Running-Times

One Battery for All	 pumping water (boost) ¹ (min.)	 pumping water (eco) ² (min.)
1.5 Ah	10	14
2.0 Ah	15	19
2.5 Ah	17	23
3.0 Ah	20	28
4.0 Ah	30	38
5.2 Ah	36	48
6.0 Ah	40	56
8.0 Ah	60	76

Test setup:

1) BOOST (1 battery)

2) ECO (1 battery)