



# Einhell

## PROFESSIONAL



**Cordless All Purpose Saw**  
**TP-AP 18/32 Li BL - Solo**  
**Item No.: 4326295**

Ident No.: 21014

Bar Code: 4006825684438

The Einhell Professional Cordless Reciprocating Saw TP-AP 18/32 Li BL – Solo is part of the Power X-Change family. Powered by an Einhell brushless motor, it delivers more power and longer runtime, with a 10-year motor warranty upon online registration. With a 32 mm stroke, it ensures precise cuts, handling up to 300 mm in wood and 20 mm in steel. Speed control and overload protection offer safe handling. A tool-free blade change and an adjustable, removable base plate allow flexible working. A scaffold hook enables convenient storage, while the LED light ensures optimal illumination. Supplied with 2 blades, battery not included.

## Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Brushless motor – more power and longer runtime
- Brushless – 10-year motor warranty upon registration
- Adjustable dial for pre-selecting maximum speed
- Precise speed control within the pre-selected range
- Switchable pendulum action for faster cuts
- LED light for illuminating the work area
- Scaffold hook for temporary storage on scaffolding and ladders
- Tool-free adjustable and tiltable saw shoe
- Saw blade can be rotated 180° for comfortable overhead work
- Tool-free blade replacement for quick application
- Low-vibration operation thanks to anti-vibration function
- Softgrip surfaces for comfortable operation
- Includes 1x wood saw blade
- Includes 1x metal saw blade
- Delivery without battery and charger (available separately)



## Technical Data

- |                             |                        |
|-----------------------------|------------------------|
| - Number of strokes         | 3000 min <sup>-1</sup> |
| - Stroke height             | 32 mm                  |
| - Cutting depth in wood     | 300 mm                 |
| - Cutting depth in plastic  | 30 mm                  |
| - Cutting depth in steel    | 20 mm                  |
| - Toolless saw blade change | yes                    |



## Logistic Data

- |                                      |                    |
|--------------------------------------|--------------------|
| - Product weight                     | 3.42 kg            |
| - Gross weight single packaging      | 4.13 kg            |
| - Dimensions single packaging        | 483 x 182 x 110 mm |
| - Pieces per export carton           | 2 Pieces           |
| - Gross weight export carton         | 8.75 kg            |
| - Dimensions export carton           | 500 x 240 x 205 mm |
| - Container quantity (20"/40"/40"HC) | 2276   4714   5528 |

## Available as special accessories



E-Case L with wheels  
System Carrying Case  
Item No.: 4540014  
Bar Code: 4006825660562  
Einhell Accessory



E-Case Tasche  
System Carrying Case  
Item No.: 4540036  
Bar Code: 4006825677966  
Einhell Accessory



E-Case M  
System Carrying Case  
Item No.: 4540021  
Bar Code: 4006825667721  
Einhell Accessory



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC 18V 3,0Ah  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



PXC 18V 2,5Ah  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Sä-Sägebl, Set 3tg Ho/Met Akku  
Universalsägen-Zubehör  
Item No.: 49576105  
Bar Code: 4009315761053  
Einhell Accessory



E-Case S-F  
System Carrying Case  
Item No.: 4540011  
Bar Code: 4006825653991  
Einhell Accessory



E-Case Werkzeugkiste  
System Carrying Case  
Item No.: 4540037  
Bar Code: 4006825677973  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210



2x18V 4,0Ah PXC-Twinpack CB  
C1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory

# Battery-Running-Times



sawing<sup>1</sup>  
(number of)

One Battery for All

1.5 Ah	166
2.0 Ah	221
2.5 Ah	276
3.0 Ah	331
4.0 Ah	441
5.2 Ah	573
6.0 Ah	661
8.0 Ah	881

For best performance select a battery with at least 3.0 Ah

Test setup:

1) wood - round soft wood Ø 35 mm