



#### **Cordless Circular Saw**

TP-CS 18/165 Li BL - Solo

Item No.: 4331225 Ident No.: 21013 Bar Code: 4006825677881

The Einhell Professional Cordless Circular Saw TP-CS 18/165 Li BL - Solo is compact and easy to handle for comfortable working. It is part of the Power X-Change family and is driven by an Einhell brushless motor for more power and a longer runtime. A 10-year motor warranty is offered after online registration. With its Ø 165 mm blade, it achieves cuts up to 59 mm deep at 90°. Safety features such as soft start and electric motor brake protect the user and the motor. Cutting aids like the rip fence and a robust saw table including a cutting line indicator ensure precise results. Supplied with a saw blade, without battery or charger.

### **Features & Benefits**

- Member of the Power X-Change family, 1x 18 V battery required
- Brushless motor more power and longer running time
- Brushless 10-year motor warranty after registration
- Comfortable working due to compact design
- Simple, tool-free adjustment (cutting depth, angle inclination)
- Easy saw blade change thanks to spindle lock
- High-quality aluminium saw table
- Rip fence for precise cuts
- Cutting line indicator for sawing after scribing
- Integrated LED light to illuminate the work area
- Vacuum adapter for a clean workspace
- Large handle with soft grip
- Soft start and electric motor brake protect user and motor
- Compatible with the Einhell guide rail
- Compatible with 16 mm and 20 mm bore diameter blades
- Incl. 1x carbide-tipped saw blade
- Supplied without battery and charger (sold separately)

## **Technical Data**

- No-load speed	
- Saw Blade	
- Number of saw teeth	
- Cutting depth at 90°	

- Cutting depth at 45°

## Logistic Data

- Product weight
- Gross weight single packaging
- Dimensions single packaging
- Pieces per export carton
- Gross weight export carton
- Dimensions export carton
- Container quantity (20"/40"/40"HC)









Illustrations can contain accessories, which are not included in standard extent of delivery Illustration similar (in design), production-wise modifications reserver GS mark belongs to the product itself only, excluded accessory Generated at: 15.11.2024 11:4 Page <sup>a</sup>



333 x 193 x 317 mm

400 x 347 x 336 mm

1120 | 2410 | 2800

2.9 kg

4.2 kg

8.9 kg

2 Pieces

#### Available as special accessories



5,2 Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory

PXC+ 18V 4,0Ah SEALED Battery Item No.: 4511627

Bar Code: 4006825673227

PXC+ 18V 3,0Ah SEALED

Bar Code: 4006825672794 **Einhell Accessory** 

**Einhell Accessory** 

Item No.: 4511618

Battery







3,0 Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory



4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory

2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 **Einhell Accessory** 

18V 3Ah PXC Plus Twinpack Battery Item No.: 4511631

2x2 Power X-Quattrocharger 4A

Bar Code: 4006825673692

**Einhell Accessory** 

Item No.: 4512102 Bar Code: 4006825649536

**Einhell Accessory** 

Charger Item No.: 4512069

Einhell Accessory

Charger







18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory

Power X-Twincharger 3A

Bar Code: 4006825629729



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory









2,0 Ah Power X-Change Battery Item No.: 4511395













Charger Item No.: 4512113 Bar Code: 4006825655377







18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143 Bar Code: 4006825667653 Einhell Accessory

E-Case L with wheels System Carrying Case Item No.: 4540014 Bar Code: 4006825660562 Einhell Accessory



PXC+ 18V 4,0Ah Battery Item No.: 4511553 Bar Code: 4006825660869 **Einhell Accessory** 

PXC 18V 3,0Ah Battery Item No.: 4511341 Bar Code: 4006825590593 **Einhell Accessory** 

Bar Code: 4006825610369 Einhell Accessory

4-6 Ah Multi-Ah Power X-Change Plus Battery Item No.: 4511502 Bar Code: 4006825644210

18V 4Ah PXC Plus Twinpack Battery Item No.: 4511629 Bar Code: 4006825673685 Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB B1 Battery Item No.: 4511489 Bar Code: 4006825638578

Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228

**Einhell Accessory** Power X-Car Charger 3A

**Einhell Accessory** 18V 4,0Ah PXC Starter Kit A1 PXC-Starter-Kit

Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory

# **Battery-Running-Times**

One Battery for All	sawing <sup>1</sup>
	(m)
1.5 Ah	18
2.0 Ah	24
2.5 Ah	30
3.0 Ah	36
4.0 Ah	48
5.2 Ah	62
6.0 Ah	72
8.0 Ah	96

For best performance select a battery with at least 2.5 Ah

Test setup:

1) wood - chipboard 19 mm