



Einhell

EXPERT



Cordless Circular Saw

TE-CS 18/165-2 Li - Solo

Item No.: 4331230

Ident No.: 21014

Bar Code: 4006825681055

The Einhell cordless circular saw TE-CS 18/165-2 Li - Solo features a compact, lightweight design and cordless flexibility. As part of the Power X-Change range, it is compatible with all system batteries and chargers. With a maximum cutting depth of 57 mm and adjustable bevel angle, settings can be changed without tools. The spindle lock allows easy blade changes for 165 mm saw blades with a 20 mm bore. LED lighting ensures visibility, while the dust extraction adapter keeps the workspace clean. Includes a parallel guide and is compatible with the Einhell guide rail. Battery and charger not included.

Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Comfortable operation due to compact design
- Easy, tool-free adjustment (cutting depth, tilt angle)
- Easy blade change thanks to spindle lock
- High-quality aluminium baseplate
- Parallel guide for precise cuts
- Integrated LED light to illuminate the workspace
- Dust extraction adapter for a clean workspace
- Soft start to protect user and motor
- Compatible with the Einhell guide rail
- Includes 1x carbide-tipped saw blade
- Supplied without battery and charger (available separately)




Technical Data

- | | |
|------------------------|------------------------|
| - No-load speed | 4200 min ⁻¹ |
| - Saw Blade | Ø165 mm |
| - Number of saw teeth | 24 Pieces |
| - Cutting depth at 90° | 57 mm |
| - Cutting depth at 45° | 39 mm |



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight | 2.9 kg |
| - Gross weight single packaging | 3.97 kg |
| - Dimensions single packaging | 346 x 201 x 306 mm |
| - Pieces per export carton | 2 Pieces |
| - Gross weight export carton | 10 kg |
| - Dimensions export carton | 430 x 360 x 320 mm |
| - Container quantity (20"/40"/40"HC) | 1130 2340 2744 |



Available as special accessories



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory

Battery-Running-Times



One Battery for All

1.5 Ah	17
2.0 Ah	23
2.5 Ah	28
3.0 Ah	32
4.0 Ah	45
5.2 Ah	59
6.0 Ah	68
8.0 Ah	90

Test setup:
1) wooden board - chipboard 19 mm