



Einhell

EXPERT



Cordless Multicutter

TE-UC 18/6 Li - Solo

Item No.: 4432010

Ident No.: 21014

Bar Code: 4006825683455

The Einhell Cordless Universal Cutter TE-UC 18/6 Li - Solo is the perfect helper for household and workshop tasks. As part of the Power X-Change family, any battery and charger are compatible with the cutter. It features a pre-installed, self-sharpening blade that cuts materials like cardboard, carpet, leather, and more, up to 6 mm thick. The cutting line indicator and LED light ensure precise cuts and optimal visibility of the cutting edge. A locking switch and soft-grip handle provide fatigue-free operation. The universal cutter is supplied without a battery and charger.

Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Effortless cutting of cardboard, textiles, etc., up to 6 mm
- Switch with locking function for comfortable continuous use
- Low maintenance thanks to self-sharpening blade
- LED light to illuminate the cutting area
- Practical cutting line guide for precision
- Handy and ergonomic handle with softgrip
- Includes pre-installed round blade
- Delivered without battery and charger (available separately)



Technical Data

- | | |
|------------------------------|-----------------------|
| - Battery voltage | 18 V |
| - No-load speed | 400 min ⁻¹ |
| - Max. cutting thickness | 6 mm |
| - Diameter main blade | 44 mm |
| - Sound pressure level (Lpa) | 62 dB (A) |

Logistic Data

- | | |
|--------------------------------------|----------------------|
| - Product weight | 0.52 |
| - Gross weight single packaging | 0.71 |
| - Dimensions single packaging | 302 x 105 x 87 mm |
| - Pieces per export carton | 8 Pieces |
| - Gross weight export carton | 6.15 kg |
| - Dimensions export carton | 440 x 315 x 190 mm |
| - Container quantity (20"/40"/40"HC) | 7920 16544 19968 |



SWITCH FOR CONTINUOUS ON



LED WORKING LIGHT



CUTTING LINE INDICATOR



Available as special accessories



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory

Battery-Running-Times



cutting¹
(m)

One Battery for All	
1.5 Ah	170
2.0 Ah	227
2.5 Ah	284
3.0 Ah	340
4.0 Ah	454
5.2 Ah	590
6.0 Ah	681
8.0 Ah	908

Test setup:

1) carton board - carton board 4 mm - ON