



Einhell

EXPERT

POWER X-CHANGE

Cordless Multiple Sander TE-OS 18/150-2 Li - Solo

Item No.: 4460790

Ident No.: 21015

Bar Code: 4006825685633

Perfect for precise sanding on corners, edges and small surfaces: the TE-OS 18/150-2 Li is part of the Einhell Power X-Change family and compatible with all batteries and chargers in the range. This compact multi-sander with soft grip sits securely in the hand. The two-part sanding plate features a rotatable tip that can be turned by loosening the screws — extending its service life. The sanding shoe measures 150 x 150 x 100 mm, with a 2 mm oscillation circuit. The active dust extraction system with collection box and filter, along with the extraction adapter for wet and dry vacuum cleaners, ensures a clean workspace. Six sanding sheets (P80, P120, P240) are included. Battery and charger are available separately.

Features & Benefits

- Part of the Power X-Change family, 1x 18V battery required
- Compact, handy delta sanding pad
- Ideal for sanding corners, edges & medium-sized surfaces
- Two-part sanding pad with rotating tip
- Ergonomic grip surface with softgrip
- Suction connection also fits Einhell wet/dry vacuums
- Includes dust collection box with pleated filter
- Includes 6 sanding sheets (2x P80, P120, P240)
- Supplied without battery and charger (sold separately)





Technical Data

- Oscillating speed 24000 min⁻¹
- Oscillating circuit 2 mm
- Grinding (sanding) surface (delta) 150 x 150 x 100
- Sanding paper size 150 x 150 x 100 mm



Logistic Data

- Product weight (kg) 0.862
- Gross weight (kg) 1.53
- Dimensions single packaging 222 x 156 x 162 mm
- Pieces per export carton 6 Pieces
- Gross weight of export carton 11 kg
- Dimensions Export Carton 490 x 238 x 342 mm
- Container quantity (20"/40"/40"HC) 3852 | 7884 | 9198



Available as special accessories



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory



E-Case L with wheels SEALED
System Carrying Case
Item No.: 4540054
Bar Code: 4006825687088
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
C1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



15 Q-Stick Schleifd. 150x100mm
Multischleifer-Zubehör
Item No.: 49496174
Bar Code: 4009314961744
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



E-Case M SEALED
System Carrying Case
Item No.: 4540053
Bar Code: 4006825687071
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Battery-Running-Times



running time¹
(min.)

One Battery for All

One Battery for All	running time ¹ (min.)
1.5 Ah	34
2.0 Ah	45
2.5 Ah	56
3.0 Ah	67
4.0 Ah	89
5.2 Ah	116
6.0 Ah	134
8.0 Ah	178

Test setup:

1) no-load