



Einhell

EXPERT



Cordless Impact Drill

TE-CD 18/2 Li-i Kit

Item No.: 4513834

Ident No.: 21033

Bar Code: 4006825614695

The Einhell TE-CD 18/2 Li-i Kit cordless impact drill driver is a powerful complete package for all jobs involving screwing, drilling and impact drilling in hard material. Supplied with 2 li-ion rechargeable batteries (1.5 Ah each) and a high-speed charger from the PXC series, it is always ready for use. The batteries are small, light & handy, have zero discharge and can be used in all the devices from the system series. The 2-speed gearing delivers plenty of power for screwdriving and high-speed drilling, the high-quality 13 mm quick-change metal drill chuck enables tools to be changed quickly. The integrated LED light illuminates the work area. For safety there is a quick stop function. Complete with a practical transport & storage case.

Features & Benefits



- Member of the Power X-Change family
- Li-ion battery: no self-discharging, small, light, easy to handle
- 3 functions: screwdriving, drilling, impact drilling in masonry
- 2-speed gearing for powerful screwdriving and fast drilling
- High-quality 13 mm quick-change drill chuck made of metal
- Quick-stop function
- Including LED lamp to illuminate the work area
- Incl. 2 x 1,5 Ah rechargeable batteries and high-speed charger
- Practical storage and carrying bag

Technical Data

- Accumulator	18 V 1500 mAh Li-Ion
- Charging time	1/2h
- Number of gears	2
- Idle speed (gear 1)	0-350 min ⁻¹
- Idle speed (gear 2)	0-1250 min ⁻¹
- Max. torque hard	44 Nm
- Number of torque steps	20 settings
- Drill chuck	13 mm single sleeve
- Drilling capacity in concrete	8 mm
- Impact rate (gear 1)	0-5250 min ⁻¹
- Impact rate (gear 2)	0-18750 min ⁻¹
- Number of accumulators	2 Pieces

Logistic Data

- Product weight	1.54 kg
- Gross weight single packaging	4.38 kg
- Pieces per export carton	2 Pieces
- Gross weight export carton	9.3 kg
- Dimensions export carton	460 x 345 x 320 mm
- Container quantity (20"/40"/40"HC)	1096 2200 2672



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory

Power X-Caravan Charger 3A Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 4,0Ah SEALED PXC Plus A1 Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



Power X-Boostcharger 8A Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



PXC Battery Protector PXC-Battery Accessory
Item No.: 4140151
Bar Code: 4006825670844
Einhell Accessory



18V 3,0Ah SEALED PXC Plus A2 Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578