



Einhell

EXPERT

POWER X-CHANGE

Cordless Light

TE-CL 18/1000 S Li - Solo

Item No.: 4514180

Ident No.: 21013

Bar Code: 4006825679076

The Einhell TE-CL 18/1000 S Li - Solo cordless lamp brings light into the dark and is part of the Einhell Power X-Change family. The light head is foldable and allows three light settings: Both panels light up together or individually. The 1,000 lumens of luminous flux provided by the 15 bright LEDs enable illumination over a short distance of up to 5 m. Bright light conditions are created by a neutral-white light colour of 5700 K. With the numerous fastening options, such as eyelets and a fastening hook, there are no limits to the possible applications. The cordless lamp TE-CL 18/1000 S Li-Solo is delivered without a battery or charger.

Features & Benefits


- Member of the Power X-Change family, 1x 18 V battery required
- Lighting conditions almost similar to daylight
- 15 powerful LEDs
- Ideal illumination for short distances
- High flexibility due to foldable light head
- Lamp consisting of two light strips
- Suspension hooks and eyelets for flexible attachment and storage
- Slim, lightweight design
- Ergonomic handle with softgrip
- Delivery does not include a battery or charger (sold separately)

Technical Data

- Voltage	18 V
- Quantity of LED	15 Pieces
- Luminous flux max.	1000 lm
- Luminous colour	5700 K

Logistic Data

- Product weight	0.46
- Gross weight single packaging	0.8
- Dimensions single packaging	372 x 115 x 113 mm
- Pieces per export carton	6 Pieces
- Gross weight export carton	5.2 kg
- Dimensions export carton	385 x 345 x 235 mm
- Container quantity (20"/40"/40"HC)	5760 11880 13068



Available as special accessories



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory

Battery-Running-Times



shining¹
(min.)

One Battery for All

1.5 Ah	109
2.0 Ah	145
2.5 Ah	181
3.0 Ah	217
4.0 Ah	289
5.2 Ah	376
6.0 Ah	434
8.0 Ah	578

Test setup:

1) Max. brightness setting