



# Einhell

## PROFESSIONAL



### Cordless Demolition Hammer TP-DHD 18/41 Li BL +4 S-F

Item No.: 4514192

Ident No.: 21015

Bar Code: 4006825687606

The Einhell Professional cordless demolition hammer TP-DHD 18/41 Li BL +4 S-F is the ideal for lighter demolition and chiselling jobs. With its 4.0 J impact force, constant electronics feature, flexible battery power and a variable impact rate control plus a continuous operation lock, it removes concrete burrs, tiles or plaster and is perfect for renovations. The tool is powered by an Einhell brushless motor for extra power and longer running times. Once you register, there is a 10-year warranty on the motor. With its SDS Plus mount, chisels can be replaced quickly and their position adjusted to 16 settings. Incl. 1 pointed and 3 flat chisels, plus an E-Case S-F. Battery and charger not included.

## Features & Benefits

- Member of the Power XChange family, 1 x 18 V battery required
- Brushless motor – more power and longer running times
- Brushless – 10-year warranty on motor after registration
- Compact and powerful demolition hammer for light demolition work
- Variable impact rate control for material-appropriate operation
- Vibration-damped handle for optimum use
- Adjustable auxiliary handle for greater comfort
- 16-level chisel adjustment
- SDS-Plus tool holder with semi-automatic operation
- Continuous operation trigger lock for time-consuming jobs
- Integrated LED light to illuminate your working area
- Includes 1 pointed and 3 flat chisels
- Supplied in E-Case S-F for transport and storage
- Battery and charger not included (available separately)



**PXC BATTERY**  
BATTERY & CHARGER  
NOT INCLUDED

## Technical Data

- Voltage 18 V
- Impact rate 0-4600 min<sup>-1</sup>
- Impact power 4 J

## Logistic Data

- Product weight (kg) 2.93
- Gross weight (kg) 6.29
- Dimensions single packaging 442 x 132 x 336 mm
- Pieces per export carton 3 Pieces
- Gross weight of export carton 22.4 kg
- Dimensions export carton 450 x 405 x 350 mm
- Container quantity (20"/40"/40"HC) 1170 | 2340 | 2730



COMPACT & LIGHTWEIGHT

ANTI-VIBRATION

**PXC BATTERY**  
BATTERY & CHARGER  
NOT INCLUDED

**BEST  
PERFORMANCE  
≥ 2.5 Ah  
BATTERY**

**18 V**

**SDS  
plus**

## Available as special accessories



E-Case L with wheels  
System Carrying Case  
Item No.: 4540014  
Bar Code: 4006825660562  
Einhell Accessory



E-Case Tasche  
System Carrying Case  
Item No.: 4540036  
Bar Code: 4006825677966  
Einhell Accessory



E-Case S-F  
System Carrying Case  
Item No.: 4540011  
Bar Code: 4006825653991  
Einhell Accessory



E-Case M  
System Carrying Case  
Item No.: 4540021  
Bar Code: 4006825667721  
Einhell Accessory



E-Case Werkzeugkiste  
System Carrying Case  
Item No.: 4540037  
Bar Code: 4006825677973  
Einhell Accessory



E-Case S-F SEALED  
System Carrying Case  
Item No.: 4540052  
Bar Code: 4006825687033  
Einhell Accessory



E-Case M SEALED  
System Carrying Case  
Item No.: 4540053  
Bar Code: 4006825687071  
Einhell Accessory



E-Case L with wheels SEALED  
System Carrying Case  
Item No.: 4540054  
Bar Code: 4006825687088  
Einhell Accessory



5,2 Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



PXC+ 18V 5-8Ah MULTI  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



3,0 Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



PXC+ 18V 4,0Ah  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



PXC 18V 3,0Ah  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



2,0 Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



4,0 Ah Power X-Change  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change  
Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210



PXC 18V 2,5Ah  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB  
C1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory

# Battery-Running-Times



chiseling<sup>1</sup>  
(min.)

One Battery for All	
1.5 Ah	11
2.0 Ah	15
2.5 Ah	19
3.0 Ah	23
4.0 Ah	30
5.2 Ah	39
6.0 Ah	45
8.0 Ah	60

For best performance select a battery with at least 2.5 Ah

Test setup:

1) brick stone - brick stone - Max. electronic speed