



Einhell

PROFESSIONAL



Power Tool Kit

TP-18V Twin Pack BL

Item No.: 4514209

Ident No.: 21023

Bar Code: 4006825664447

The Einhell 18V Brushless Twin Pack Power Tool Kit consists of the TP-CD 18/50 Li-i BL Cordless Impact Drill and the TE-CI 18 Li BL Cordless Impact Driver. Both tools are part of the Power X-Change family and are equipped with a PUREPOWER brushless motor with a 10-year warranty (after registration), which provides more power and longer running times. The 2-speed gearbox of the cordless impact driver is suitable for powerful drilling and screwing. Tightening large and long screws is an effortless task with the cordless impact driver fitted with a 1/4" hexagon tool chuck. Supplied with 2x 2.0Ah Einhell Power X-Change rechargeable batteries, a fast charger and a practical transport bag.

Features & Benefits



- Member of the Power X-Change family, 1x 18 V battery required
- Brushless motor – more power and longer running time
- PurePOWER Brushless - 10 year motor warranty after registration
- Tool set consisting of cordless impact driver and cordless impact
- Impact driver with 13 mm metal chuck
- Impact driver with 2-speed gearbox for drilling and screwing
- Speed electronics for material- and application-appropriate work
- Impact driver for easily screwing in large and long screws
- Impact driver with impact mechanism for protecting the wrists
- Impact driver with 6.35 mm (1/4") hexagon socket
- Impact driver in ergonomic and lightweight design with softgrip
- Impact drill and impact driver with LED light
- Delivery incl. two 2.0 Ah Power X-Change batteries and charger
- Includes bag for easy transport



Technical Data

Logistic Data

- Product weight (kg)	3.1
- Gross weight (kg)	5.6
- Dimensions single packaging	440 x 130 x 325 mm
- Product weight	3.1 kg
- Pieces per export carton	2 Pieces
- Gross weight export carton	11.8 kg
- Gross weight single packaging	5.6 kg
- Dimensions export carton	455 x 280 x 355 mm
- Container quantity (20"/40"/40"HC)	1220 2540 2980



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory

Power X-Caravan Charger 3A Charger
Item No.: 4512136
Bar Code: 4006825664010
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V 4,0Ah SEALED PXC Plus A1 Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



18V 3Ah PXC Plus Twinpack Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



Power X-Boostcharger 8A Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



PXC Battery Protector PXC-Battery Accessory
Item No.: 4140151
Bar Code: 4006825670844
Einhell Accessory



18V 3,0Ah SEALED PXC Plus A2 Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



18V 4Ah PXC Plus Twinpack Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578