



Einhell

CLASSIC



Cordless Drill

TC-CD 18/38 Li - Solo

Item No.: 4514365

Ident No.: 21015

Bar Code: 4006825686159

The Einhell Cordless Drill Driver TC-CD 18/38 Li-Solo is a compact member of the Power X-Change family. With up to 38 Nm torque, 21 torque settings and a drilling stage, it is a reliable helper for various screwdriving and drilling tasks. Speed electronics enable precise adjustment of power to suit the material and application, while the torque slip clutch prevents over-tightening of screws. Drill and screwdriver bits can be changed quickly thanks to the 10 mm double-sleeve quick-change chuck and Quick Stop function. An LED light ensures good visibility. Supplied without battery or charger.

Features & Benefits


- Member of the Power X-Change family, 1x 18 V battery required
- Metal gearbox for powerful drilling and screwdriving
- Speed control for work suited to the material
- Torque slip coupling prevents screw over-tightening
- 10 mm quick-release chuck for fast tool changes
- Quick-stop for fast and easy tool changes
- Integrated LED lights up the working area
- Ergonomic design with soft grip
- Supplied without battery and charger (sold separately)

Technical Data

- | | |
|--------------------------|-----------------------|
| - Number of gears | 1 |
| - Idle speed (gear 1) | 550 min ⁻¹ |
| - Max. torque hard | 38 Nm |
| - Number of torque steps | 21+1 settings |
| - Drill chuck | 10 mm double sleeve |

Logistic Data

- | | |
|--------------------------------------|----------------------|
| - Product weight | 1.03 kg |
| - Gross weight single packaging | 1.52 kg |
| - Dimensions single packaging | 198 x 95 x 227 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 6.6 kg |
| - Dimensions export carton | 400 x 215 x 245 mm |
| - Container quantity (20"/40"/40"HC) | 5000 10680 12400 |



Available as special accessories



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
C1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Battery-Running-Times



screwing¹
(pieces)

One Battery for All

1.5 Ah	230
2.0 Ah	305
2.5 Ah	380
3.0 Ah	460
4.0 Ah	610
5.2 Ah	790
6.0 Ah	920
8.0 Ah	1220

Test setup:

1) softwood - 6x60 mm