



Einhell

CLASSIC



Cordless Angle Grinder

TC-AG 18/8500 Li - Solo

Item No.: 4514410

Ident No.: 21024

Bar Code: 4006825675399

The Einhell cordless angle grinder TC-AG 18/8500 Li - Solo is a versatile assistant for cutting, grinding, and polishing tasks. With 8,500 RPM and a cutting depth of 33 mm, it handles demanding jobs with ease. As a member of the Power X-Change family, it is compatible with all batteries in the range. The angle grinder supports cutting discs with a diameter of Ø 125 mm. Soft start, restart protection, and overload protection ensure safety and durability. The tool-free adjustable disc guard and cutting guard provide additional protection. The ergonomic additional handle can be mounted in three positions for greater flexibility. Battery, charger, and cutting disc are not included and must be purchased separately.

Features & Benefits

- Member of the Power X-Change family, requires 1x 18V battery
- Soft start and restart protection for enhanced user safety
- Overload protection for long service life
- Tool-free adjustable disc guard for flexible work
- Cutting guard for maximum safety during cutting
- Durable aluminium gear housing
- Additional handle mountable in three positions
- Recommended for optimal results: 2.5 Ah battery or larger
- Delivered without cutting disc
- Delivered without battery and charger (available separately)



Technical Data

- | | |
|-------------------------------------|------------------------|
| - Disc size | 125 mm |
| - No-load speed (idle speed) Max. | 8500 min ⁻¹ |
| - Max. cutting depth | 33 mm |



Logistic Data

- | | |
|--------------------------------------|--------------------|
| - Product weight (kg) | 1.7 |
| - Gross weight (kg) | 2.16 |
| - Dimensions single packaging | 350 x 145 x 120 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight of export carton | 9.1 kg |
| - Dimensions Export Carton | 488 x 378 x 187 mm |
| - Container quantity (20"/40"/40"HC) | 3020 6500 7540 |



Available as special accessories

	Trennschutz TC-WS 18 Li Angle Grinder Accessory Item No.: 4450060 Bar Code: 4006825675542 No Name		5,2 Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606 Einhell Accessory
	PXC+ 18V 5-8Ah MULTI Battery Item No.: 4511600 Bar Code: 4006825665055 Einhell Accessory		PXC 18V 4,0Ah Battery Item No.: 4514079 Bar Code: 4006825674316 Einhell Accessory (Discounter)
	PXC+ 18V 4,0Ah SEALED Battery Item No.: 4511627 Bar Code: 4006825673227 Einhell Accessory		PXC+ 18V 4,0Ah Battery Item No.: 4511553 Bar Code: 4006825660869 Einhell Accessory
	PXC+ 18V 3,0Ah SEALED Battery Item No.: 4511618 Bar Code: 4006825672794 Einhell Accessory		PXC 18V 3,0Ah Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory
	3,0 Ah Power X-Change Plus Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory		2,0 Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory
	4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 Einhell Accessory		4-6 Ah Multi-Ah Power X-Change Plus Battery Item No.: 4511502 Bar Code: 4006825644210
	2x 18V 5,2Ah PXC-Twinpack Battery Item No.: 4511526 Bar Code: 4006825656695 Einhell Accessory		18V 4Ah PXC Plus Twinpack Battery Item No.: 4511629 Bar Code: 4006825673685 Einhell Accessory
	18V 3Ah PXC Plus Twinpack Battery Item No.: 4511631 Bar Code: 4006825673692 Einhell Accessory		2x18V 4,0Ah PXC-Twinpack CB B1 Battery Item No.: 4511489 Bar Code: 4006825638578
	2x2 Power X-Quattrocharger 4A Charger Item No.: 4512102 Bar Code: 4006825649536 Einhell Accessory		Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory
	Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory		Power X-Car Charger 3A Charger Item No.: 4512113 Bar Code: 4006825655377 Einhell Accessory
	Power X-Boostcharger 8A Charger Item No.: 4512155 Bar Code: 4006825670554 Einhell Accessory		18V Battery Charger 3,0A - PXC Charger Item No.: 4514095 Bar Code: 4006825655292 Einhell Accessory
	18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory		2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit Item No.: 4512112 Bar Code: 4006825655766 Einhell Accessory
	18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit Item No.: 4512143 Bar Code: 4006825667653 Einhell Accessory		18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory
	5,2 Ah PXC Starter-Kit PXC-Starter-Kit Item No.: 4512147 Bar Code: 4006825675153 Einhell Accessory		18V 4,0Ah PXC Starter Kit B1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory

Battery-Running-Times

One Battery for All

1.5 Ah
2.0 Ah
2.5 Ah
3.0 Ah
4.0 Ah
5.2 Ah
6.0 Ah
8.0 Ah

Test setup: